




eBirdSoft Report B13992

Simulation : False
Vessel : Ranform Atlas
Date : Wed May 3 23:21:07 2017
Author : Berenguer Yoann
Version : beta 1.01



Page :1

Body Condition monitoring

Body QC checks

- Firmware version
- Rotation
- Roll
- Humidity
- Pressure
- Temperature
- Depth

Pressure calibration

- Test at 0m
- Test at 10m
- Test at 20m
- Sensor coefficient

Monitoring

- Temperature & humidity
- Roll 3d graph
- Polar graph
- Power L1 & L2
- Currents L1
- Currents L2



Atmospheric pressure: 1010

Body firmware : 2.02.00



Body serial number : 13992



Body rotation QC

Maximum rotation: 1.0



Ideally, the rotation count should be set to zero.

Minimum rotation: 0.0



Average rotation: 0.13



Body roll QC

Maximum roll : 180.0



Minimum roll : -179.9



Average roll : 153.68



Body humidity QC

Maximum humidity : 67.5%



Humidity is high

Minimum humidity : 67.1%



Average humidity : 67.12%



High humidity, need investigation

Body pressure QC

Maximum pressure : 1012.0 mB



DT needs recalibration

Minimum pressure : 1011.0 mB



DT needs recalibration

Average pressure : 1011.98 mB



DT needs recalibration

Body temperature QC

Maximum temperature : 30.4



Minimum temperature : 30.4



Average temperature : 30.4



Body depth QC

Maximum depth : -0.01



Minimum depth : -0.02



Average depth : -0.01






Body temperature,humidity,pressure & depth

Scan interval :2.0 seconds

Records : from 1 to 33

Time window : from 2.0s to 66.0 s

Page :3





Body Rotation and roll


Scan interval :2.0 seconds

Records : from 1 to 33


Time window : from 2.0s to 66.0 s

Page :4

Roll 3D graph



Polar^{90°} graph





Power L1 and L2

Scan interval :2.0 seconds

Records : from 1 to 33


Time window : from 2.0s to 66.0 s

Page :5

L1 mode : On

L2 mode : On

Power plots





Currents L1

Scan interval :2.0 seconds

Records : from 1 to 33

Time window : from 2.0s to 66.0 s

Page :6

Leakage detection

Leakage detected: no



Leakage recurrence: None



Leakage maximum: 0.0




Leakage average: -0.06



Leakage minimum: -1.0



L1 current plots





Currents L2

Scan interval :2.0 seconds

Records : from 1 to 33

Time window : from 2.0s to 66.0 s

Page :7

Leakage detection

Leakage detected: no



Leakage recurrence: None



Leakage maximum: 0.0




Leakage average: -0.06



Leakage minimum: -1.0




L2 current plots





Element : - Firmware outdated	Severity: 0	Pass
Element : - Rotation count	Severity: 1	Notice
Element : - Humidity	Severity: 2	Warning
Element : - DT recalibration	Severity: 4	Fail
Element : - Temperature	Severity: 0	Pass
Element : - DT test @0m	Severity: 0	Pass
Element : - DT test @10m	Severity: 0	Pass
Element : - DT test @20m	Severity: 0	Pass
Element : - Leakage L1	Severity: 0	Pass
Element : - Leakage L2	Severity: 0	Pass

Fail





IFS

Scan interval :2.0 seconds

Records : from 1 to 33

Time window : from 2.0s to 66.0 s

Page :9

Item found in IFS

Description	eBird? Body GeoStreamer
Vessel	SOS
Part number	1021569
Serial number	B13992
Alternate ID	5380622
Operational condition	Non Operational
Operational status	Not Applicable
Latest transaction	Moved to location ATS-3-3298 at site ATS
Date created	2014-01-16 10:27:09
Date changed	2017-04-14 19:51:46

Active work order

WO number	62007498
WO status	FAULTREPORT
Registration date	2017-04-11 00:42:56
Location	SOS
Description	eBird? Body GeoStreamer
Error description	TBSO - Comms problem with wing 1. Intermittent.
Symptom	510 Communication failure
Cause	None Communication failure
Error type	None
Discover code	40 Equipment Malfunction
Origin code	23

No historical work order found

Found : 0 transport order(s)



QR code

Scan interval :2.0 seconds

Records : from 1 to 33

Time window : from 2.0s to 66.0 s

Page :10

The QR code contains the following informations

S/N:B13992

PART_NO: 1021569

ALTERNATE_ID: 5380622

Body status: Fail

- Rotation count : Severity=1

- Humidity : Severity=2

- DT recalibration : Severity=4

